



# Gateway ID49C07U Battery Replacement

This guide will demonstrate how to replace the battery of this device.

Written By: Patrick McGrail



## Step 1 — Battery



- Turn the laptop over so the bottom of the device is facing upwards with the hinge facing away from you.

## Step 2



- Locate the switch on the top left of the laptop labeled with a padlock symbol.
- Flip the switch in the direction of the unlocked padlock symbol.



## Step 3



- Locate the switch that releases the battery and slide it to the right.

## Step 4



- While holding the release switch to the right, pull the battery away from you.

To reassemble your device, follow these instructions in reverse order.